

# FT-133 Williamsburg Pineapple Fountain

**Two people are recommended for the installation of this fountain!**



## FOUNTAIN INFORMATION:

This fountain holds approximately 5 gallons of water.

This fountain uses a small fountain cover.  
(FTNCOV-SM)

Compatible with #7 Refill Device  
(A special stopper is required to use the refill kit for  
this fountain.)

## Pump Kit Parts List

PK140 pump (1)  
#7 stopper (1)  
Approx. 6" length of 1/2" Black Non-kink tubing (1) \*\*  
Approx. 1" length of 5/8" clear vinyl tubing (1) \*\*  
Approx. 1" length of 1/2" CPVC pipe (1) \*\*  
Wedges (2)  
Hose clamps (1) \*

\* Hose clamps may be used as flow restrictors

\*\*Black non-kink tubing and clear vinyl tubing have been preassembled

## TOOLS REQUIRED:

Bubble Level



## PUMP INFORMATION:

OEMPF140 - 140 GPH Pump  
6 FT cord length

## - W I N T E R   C A R E -

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise, components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze;
- (4) Check fountain periodically to insure that plastic is secure and water is not accumulating in any fountain component.

## - G E N E R A L   F O U N T A I N   T I P S -

**Install fountains on a level surface.** You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

Check out YouTube for a "How to" video.

For more Campania product information visit [www.campaniainternational.com](http://www.campaniainternational.com)

All of our cast stone is proudly




Made in USA

# FT-133 Williamsburg Pineapple Fountain


Two people are recommended for the installation of this fountain!

Assemble your fountain on a level surface capable of holding a minimum of 315 pounds with an approximate 1 square foot footprint.




FT-132G (135 lbs)  
12.75"W x 25.75"H

1. Place the base (FT-132G) into position where the fountain will be installed, ensuring that it is level.




FT-132F (111 lbs)  
30"W x 8.5"H

2. Center the large bowl (FT-132F) on the base (FT-132G)
3. Assemble the pump kit
  - a. **NOTE: All pumps come with multiple adapters**
    - i. **This fountain uses the largest adapter provided.**
    - b. Using a hose clamp, attach the 1/2" end non-kink end of the tubing assembly to the pump outlet.
    - c. Place the stopper around the pump cord approximately 8" from the pump.



FT-133B (8 lbs)  
9"W x 5.75"H


4. Feed the pump cord through the hole in the large bowl (FT-132F) and through the base (FT-132G).
5. **FIRMLY** press the stopper into the hole evenly.
  - a. Note: Using the handle of a screwdriver or hammer works best to press the stopper in place.



FT-133A (17 lbs)  
7"W x 9.75"H

6. Place the pump cover (FT-133B) over the pump and in the center of the large bowl (FT-132F).

7. Insert the CPVC end of the tubing assembly into the CPVC coupling protruding from the bottom of the finial (FT-133A).
8. Center the finial (FT-133A) on the pump cover (FT-133B).
  - a. **Note: Rotating the finial as it is lowered into position will help to ensure that the tubing does not get pinched.**



FT-133C (1 lb)  
5"L x 1.25"W x 4"H

9. Fit the pump cover door (FT-133C) into the pump cover (FT-133B).

10. Fill the fountain with water.