FT-226 Passaros II Fountain Two people are recommended for the installation of this fountain!



PK300 pump (1) #10 stopper (1) Approx. 20" length of 1/2" Black non-kink tubing (1) ** Approx. 2" length of 5/8" clear tubing (1) ** 2" length of 1/2" CPVC pipe (1) ** Wedges (2) Hose clamps (3) *

Pump Kit Parts List

*Hose clamps can be used as flow restrictors.

FOUNTAIN INFORMATION:

This fountain holds approximately 7 gallons of water.

This fountain uses a small fountain cover. (FTNCOV-SM)

Compatible with Refill #7 Device (A different style stopper may be requested for this part.)

TOOLS REQUIRED:

Bubble Level



PUMP INFORMATION:

OEMPF320 - 320 GPH Pump 16 FT cord length

-WINTER CARE-


Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise, components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze;
- (4) Check fountain periodically to ensure that plastic is secure and water is not accumulating in any fountain component.

-GENERAL FOUNTAIN TIPS-


Install fountains on a level surface. You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump

cord will be threaded through this opening.







Assemble your fountain on a level surface capable of holding a minimum of 300 pounds with an approximate 1 square foot footprint.



FT-226B (186 lbs) 23.5"W x 26.5"H



- 2. Assemble the pump kit.
 - a. Using a hose clamp, attach the tubing to the pump outlet.
 - b. Place the stopper around the pump cord about 6" from the pump.
- 3. Feed the pump cord all the way through the hole and the channel in the basin (FT-226B) to ensure the fountain will be level.
- 4. **FIRMLY** press the stopper into the hole evenly.
 - a. **Note:** Using the handle of a screwdriver or hammer works best.



FT-226A (52 lbs) 18.5"W x 7.5"H

- 5. Holding the water feature disc (FT-226A) over the basin (FT-226B), insert the 1/2" CPVC already connected to the tubing assembly into the CPVC coupling underneath the water feature (FT-226A).
- 6. Center the water feature (FT-226A) into basin (FT-226B).
- 7. Fill the fountain with water.