FT-280 Condotti Fountain

Three people are recommended for the installation of this fountain!



Pump Kit Parts List

PK800 Pump (1) #10 stopper (1) #7 Drain Stopper

Approx. 12" length of 1/2" Black Non-Kink tubing (1) **

2" length of 5/8" clear tubing (2) **

2" length of 3/4" clear tubing (1) **

2" length of 1/2" CPVC pipe (1) **

Wedges (2)

Hose clamps (2) *

* Hose clamps may be used as flow restrictors

**Tubing has been pre-assembled

FOUNTAIN INFORMATION:

This fountain holds approximately 25 gallons of water.

This fountain uses an extra-large fountain cover. (FTNCOV-XLG)

Compatible with #10 Refill Devise and LED kit.
(A special stopper is required to use the refill kit for this fountain.)

TOOLS REQUIRED:

Bubble Level



PUMP INFORMATION:

OEMPP800 - 800 GPH Pump 16 FT cord length

-WINTER CARE-

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze;
- (4) Check fountain periodically to ensure that plastic is secure and water is not accumulating in any fountain component.

-GENERAL FOUNTAIN TIPS-

Install fountains on a level surface. You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel

opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

Check out YouTube for a "How to" video. For more Campania product information visit www.campaniainternational.com



FT-280 Condotti Fountain

Three people are recommended for the installation of this fountain!

Assemble your fountain on a level surface capable of holding a minimum of 1200 pounds with an approximate 4 square foot footprint.



FT-269H (392 lbs) 24"L x 24"W x 15"H



P-713 (500 lbs) 46"W x 25.25"H



FT-224D (56 lbs) 12"W x 8"H



FT-280A (10 lbs) 12"W x 5"H



FT-224E (2 lbs) 6"L x 2.5"W x 4.75"H



FT-269I (13 lbs) 8.25"L x 2.5"W x 9"H

- 1. Place the base (FT-269H) into position where the fountain will be installed, ensuring that it is level.
- 2. Assemble the pump kit
 - a. Connect the preassembled tubing to the pump by sliding the 3/4" clear tubing over the pump outlet.
 - b. Place the stopper around the pump cord about 8" from the pump.
- 3. Center the urn (P-713) over the base (FT-269H).
- 4. Feed the pump cord through the hole in the urn (P-713) and the channel in the base (FT-269H).
- 5. **FIRMLY** press the stopper into the hole evenly.
- 6. Insert the smaller drain stopper into the small hole of the bowl.
- 7. Place the pump house (FT-224D) over the pump and in the center of the urn (P-713).
- 8. Position the water feature disc (FT-280A) over the pump house (FT-224D).
- 9. Insert the 1/2" CPVC end of the preassembled tubing into the coupling protruding from the bottom of the water feature disc (FT-280A).
- 10. Fit the small pump house door (FT-224E) into the pump house (FT-224D).
- 11. Fit the large access door (FT-269I) into the base (FT-269H).
- 12. Fill the fountain with water.