FT-285 Triad Fountain

Two people are recommended for the installation of this fountain!



FOUNTAIN INFORMATION:

This fountain holds approximately 5 gallons of water.

This fountain uses a large fountain cover. (FTNCOV-LG)

Compatible with #10 Refill Device and LED kits (A special stopper is required to use the refill kit for this fountain.)

Pump Kit Parts List

PK300 pump (1) #10 stopper (1) 12" length of 1/2" Black Non-kink tubing (1) ** 2" length of 5/8" clear tubing (1) ** Copper Spiller (1) 2.8 oz tube of Silicone (1) Wedges (3) Hose clamps (1) *

- * Hose clamps may be used as flow restrictors
- ** Tubing has been preassembled

TOOLS REQUIRED:

Bubble Level S == 1

PUMP INFORMATION:

PF320 - 320 GPH Pump 16 FT cord length

-WINTER CARE-

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise, components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze;
- (4) Check fountain periodically to insure that plastic is secure and water is not accumulating in any fountain component.

-GENERAL FOUNTAIN TIPS-

Install fountains on a level surface. You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump

cord will be threaded through this opening.

All of our cast stone is proudly


Made in USA

Check out YouTube for a "How to" video. For more Campania product information visit www.campaniainternational.com

FT-285 Triad Fountain

Two people are recommended for the installation of this fountain!

Assemble your fountain on a level surface capable of holding a minimum of 464 pounds with an approximate 1.5 square foot footprint.



FT-285E (107 lbs) 16"L x 13.5"W x 15"H




30"L x 20.25"W x 9"H

1. Place the base (FT-285E) into position where the fountain will be installed, ensuring that it is level.

- 2. Center the basin (FT-285C) on the base (FT-285E)
- 3. Assemble the pump kit
 - a. NOTE: All pumps come with 1 adapter already inserted into the pump and 2 adapters secured to the power cord.
 - i. This fountain uses the medium adapter provided.
 - b. Using a hose clamp, attach the 12" piece of 1/2" non-kink tubing to the pump outlet.
 - c. Place the stopper around the pump cord approximately 8" from the pump.
- 4. Feed the pump cord through the hole in the basin (FT-285C) and through the channel in the bottom of the base (FT-285E).
- 5. **FIRMLY** press the stopper into the hole evenly.
 - a. Note: Using the handle of a screwdriver or hammer works best to press the stopper in place.




- 7. Fit the 5/8" clear end of the tubing over the CPVC pipe protruding from the bottom of the water feature (FT-285A).
 - a. Note: You can do this step without holding the water feature over the basin and after you level it
- 8. Spread a thin bead of silicone where the spiller will be placed in the water feature (FT-285A) by creating a rectangular shape that boarders just the narrow channel.
- 9. Press the spiller into place ensuring that the bent part overhangs the water feature.
 - a. Note: Clean away any excess silicone.





FT-285A (148 lbs) 29.75"L x 9"W x 9.25"H



FT-285B (5 lbs) 4"L x 4"W x 1"H



FT-285D (2 lb) 1.25"L x 5.25"W x 3.75"H

- 11. Fit the pump cover door (FT-285D) into the pump cover (FT-285C).
- 12. Let the fountain sit 24 hours before filling with water.