

# FT-288 Falling Water IV Fountain

**Two people are recommended for the installation of this fountain!**



## FOUNTAIN INFORMATION:

**This fountain holds approximately 20 gallons of water.**

**This fountain uses a large fountain cover.  
(FTNCOV-LG)**

**Compatible with Refill Device and LED kits  
(A special stopper is not required to use the refill kit for  
this fountain.)**

## Pump Kit Parts List

PK300 Pump (1)  
12" length 1/2" non-kink hose (1) \*\*  
2" length 5/8" clear vinyl tubing (1) \*\*  
2" piece of 1/2" CPVC pipe (1) \*\*  
Hose clamps (3) \*  
2.8 oz tube of silicone (1)  
Copper Spiller  
Wedges (3)

\* Hose clamps may be used as flow restrictors

\*\*Black non-kink tubing and clear vinyl tubing have been preassembled

## TOOLS REQUIRED:

Bubble Level



## PUMP INFORMATION:

**OEMPF320 - 320 GPH Pump  
16 FT cord length**

## - W I N T E R   C A R E -

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise, components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze;
- (4) Check fountain periodically to ensure that plastic is secure and water is not accumulating in any fountain component.

## - G E N E R A L   F O U N T A I N   T I P S -

**Install fountains on a level surface.** You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

Check out YouTube for a "How to" video.

For more Campania product information visit [www.campaniainternational.com](http://www.campaniainternational.com)

**All of our cast stone is proudly**




**Made in USA**


# FT-288 Falling Water IV Fountain

**Two people are recommended for the installation of this fountain!**


Assemble your fountain on a level surface capable of holding a minimum of 354 pounds with an approximate 3 square foot footprint.




FT-288E (37 lbs)  
16.5"L x 28"W x 3"H




FT-286F (162 lbs)  
20.25"L x 30"W x 9"H




FT-287C (13 lbs)  
16.75"L x 7.5"W x 5.5"H



FT-287A (134 lbs)  
10"L x 7.5"W x 25"H



FT-287B (4 lbs)  
6.5"L x 4"W x 1"H



FT-287D (4 lbs)  
6.75"L x 1.5"W x 3.25"H

1. Position the base (FT-288E) where the fountain is to be installed, ensuring that it is level.
2. Position the basin (FT-286F) over the base.
3. Place the pump cover (FT-287C) along the back edge of the basin.
4. Assemble the pump and tubing.
  - a. Using a hose clamp, attach the 1/2" non-kink tubing to the pump outlet.
  - b. **NOTE: All pumps come with 1 adapter already inserted into the pump and 2 adapters secured to the power cord.**
    - i. **This fountain uses the medium adapter provided.**
5. Place the pump in the center of the pump cover.
6. Lay the pump cord over the edge at the back of the basin.
7. Place the water feature (FT-287A) on top of the pump cover and ensure that the pump cord exits through the hole provided.
8. Insert the 2" CPVC pipe into the coupling protruding from the bottom of the water feature (FT-286A).
9. Using the silicone provided, secure the copper spiller to the top lip of the water feature.
10. Place the spiller stopper (FT-287B) inside the top of the water feature.
11. Place the pump cover door (FT-287D) in the pump access opening of the pump cover.
12. Let the fountain sit 24 hours before filling with water to let the silicone dry completely.