

FT-320 Large M Weave Fountain

Two people are recommended for the installation of this fountain!



FOUNTAIN INFORMATION:

This fountain holds approximately 20 gallons of water.

**This fountain uses an extra-large fountain cover.
(FTNCOV-XLG)**

**Compatible with both Refill Devices and LED kits
(A special stopper is NOT required to use the refill kit
for this fountain.)**

Pump Kit Parts List

PK500 pump (1)
#7 drain stopper (1)
12" length of 1/2" Black Non-kink tubing (1) **
2" length of 5/8" clear tubing (1) **
2" length of 1/2" CPVC pipe (1) **
Wedges (3)
Hose clamps (1) *

* Hose clamps may be used as flow restrictors

** Tubing has been preassembled

TOOLS REQUIRED:

Bubble Level



Phillips or Flat Head Screwdriver

PUMP INFORMATION:

**OEMPF525 - 525 GPH Pump
16 FT cord length**

- W I N T E R C A R E -

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise, components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze;
- (4) Check fountain periodically to insure that plastic is secure and water is not accumulating in any fountain component.

- G E N E R A L F O U N T A I N T I P S -

Install fountains on a level surface. You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

Check out YouTube for a "How to" video.

For more Campania product information visit www.campaniainternational.com

All of our cast stone is proudly




Made in USA


FT-320 Large M Weave Fountain

Two people are recommended for the installation of this fountain!


Assemble your fountain on a level surface capable of holding a minimum of 1200 pounds with an approximate 6 square foot footprint.




FT-320E (468 lbs)
38"L x 25"W x 16"H




FT-320C (64 lbs)
33.5"L x 6.25"W x 8.25"H



FT-320A (561 lbs)
33"L x 7.75"W x 33.5"H



FT-320B (4 lbs)
29.25"L x 2.25"W x .75"H



FT-320D (3 lb)
5.5"L x 0.75"W x 6.75"H

1. Place the basin (FT-320E) into position where the fountain will be installed, ensuring that it is level.
 - a. Note: Be sure the drain hole is positioned toward the front of the basin.
2. Assemble the pump kit
 - a. **NOTE: All pumps come with 2 adapters.**
 - i. **This fountain uses the larger adapter provided.**
 - b. Using a hose clamp, attach the tubing assembly to the pump outlet.
3. Place the pump in the center of the pump cover (FT-320C).
4. Lay the pump cord over the edge at the back of the basin.
 - a. Note: There is a cut out in the back of the water feature (FT-320A) that will accommodate for the cord.
5. Place the water feature (FT-320A) on top of the pump cover and ensure that the pump cord exits through the hole provided.
6. Insert the CPVC pipe attached to the preassembled tubing into the coupling protruding from the bottom of the water feature (FT-320A).
7. Place the spill stopper (FT-320B) inside the top of the water feature.
8. Place the pump cover door (FT-320D) in the pump access opening of the pump cover.
9. Fill the fountain with water.